



INSTALLING THE HIDE CONCRETE SKIMMER LID

1 ESTABLISH THE FINISHED HEIGHT

Calculate the boxing/form work required so the top rim of the installed Edge Protector (C) will achieve a flush finish with the surrounding surface.

2 ALLOW FOR SLAB MOVEMENT


The Edge Protector (C) will remain in position during the slab pour, being part of the form work around the skimmer lid. A clearance/expansion joint may be necessary to allow for slab movement.

3 SELECT ELECTRICAL BONDING METHOD

If any HIDE Edge Protector is to be installed within 1 meter of a pool, equipotential bonding may need to be considered. When the Edge Protector is installed as removable, no bonding is required. An Edge Protector may be deemed removable if enough clearance is provided through an expansion joint. However, if the Edge Protector is fixed in place, bonding may be required. Please consult with your electrician or visit our website www.skimmerlids.com.au for more information.


4 FIX POSITION

Secure the Edge Protector to the boxing/form work via the predrilled holes. If required, attach the appropriate bonding links at this stage - refer to the site electrician.




5 PREP THE EDGE PROTECTOR

Apply a petroleum-based or non-stick coating to all surfaces of the Edge Protector (C) to ensure concrete residue does not bond to the stainless steel components.




6 PREP THE INLAY LID

Set the Inlay Lid (B) face-up on a flat work surface away from the main slab pour area. To achieve a seamless finish, the Inlay Lid should be filled with the same concrete mix poured directly around the skimmer box. When filling the Inlay Lid (B), be sure to allow for any finishing procedure that may change the surface height of the set concrete. Applying a petroleum-based or non-stick coating to the outside of the Inlay Lid will assist during the final clean-up.



7 CLEAN SURFACES



As soon as possible, clean any concrete residue from the exposed parts of the Edge Protector (C) and Inlay Lid (B).




WARNING!

DO NOT ALLOW ACID OR CHEMICAL WASH SOLUTIONS TO CONTACT THE HIDE PRODUCT.


If washing with acid/chemicals, take protective measures to ensure minimal contact with the stainless steel HIDE components. Before use of acid/chemical wash, apply a water-resistant lubricant to the HIDE parts. When finished, immediately clean the HIDE components thoroughly to remove residual acid/chemicals.

COMPLETED INSTALL (CROSS SECTION VIEW)




Operation requires a two handed vertical lift by **AN ADULT ONLY**. Support your back and do not lift a weight beyond your limits. Ensure Safety Keys remain in the locked position at all times. Keep feet away from the lid and recess frame at all times.


OPENING THE DOUBLE KEYWAY HIDE LID



Insert both Safety Keys and turn to 90° so they lock into the back of the lid.




Lift vertically, just enough to clear the recess.




Set safely aside. Do not carry the lid at a height.

CLOSING THE DOUBLE KEYWAY HIDE LID



Using both hands, grip each Safety Key, keeping them at a 90° position.



Position the lid above the recess and lower down vertically.



Remove both Safety Keys and store away from children.

NOTE - INSTALLATION IS ONLY COMPLETE WHEN:

NEVER leave the QUAD Safety Key in the lid for any reason, especially after install. Leaving the Safety Key in an installed lid exposes a contractor to possible legal ramifications if a resulting accident or injury occurs.

PASS the Safety Key to the homeowner for secure storage. The "Home Owners Manual" packet should also be given to the homeowner.